

cod.281M0221

TESI

Istruzioni di montaggio ed uso
Operation instructions
Instructions de montage et usage
Montage- und Bedienungsanleitung
Instrucciones de montaje y uso
Instrucțiuni pentru montare și utilizare

IRSAP

IRSAP SPA

45031 Arquà Polesine (RO) Italy
Tel. +39 0425 466611 - Fax +39 0425 466662
Website: www.irsap.com - E-mail: info@irsap.it

IR GROUP SARL

19,Chemin de la Plaine 69390 Vourles (France)
Tel. +33 04 28 00 01 67 - Fax +33 04 72 31 86 40
Web: www.irsap.com - E-mail: irsaphos@irgroup.fr






IRSAP IBERICA S.L.

Oficina y Almacén: P.I.CAMI RAL
Leonardo da Vinci,4 08850 Gavà (Barcelona)
Tel. 93 633 47 00 - Fax 93 633 47 04
E-mail: informacion@irsap.com
Web: www.irsap.com


IRROM Industrie S.R.L.

Str. Principală 1/A, Sat Fundătara, Iclod 407336,
jud. Cluj, România
Tel: +40 (0)264 263400 - Fax: +40 (0)264 263404
Web: www.irsap.ro















Accessori non inclusi-Accessoires non compris
Accessories not included-Zubehör nicht inklusive.
Accesorios no incluidos-Acesorii neincluse







TESI	Pmax (Kg)
2	75
3	52
4	160
5	100
6	64



n't.=numero elementi
n't.=number of elements
n't.=nombre de éléments
n't.=anzahl glieder
n't.=número de elementos
n't.=număr elemente



n't.=numero elementi
n't.=number of elements
n't.=nombre de éléments
n't.=anzahl glieder
n't.=número de elementos
n't.=număr elemente



n't.=numero elementi
n't.=number of elements
n't.=nombre de éléments
n't.=anzahl glieder
n't.=número de elementos
n't.=număr elemente

